

“Patent”
ONDEO Nalco Docket
No. 7628

METHOD OF TRACING DRAINS

Inventors:

Michael J. Weiland

John E. Hoots

Margaret Meta Brumm
ONDEO Nalco Company
ONDEO Nalco Center
1601 W. Diehl Road
Naperville, Illinois 60563-1198
(630) 305-1423

FIELD OF INVENTION

This invention is in the field of drains and drainage systems. Specifically, this invention is in the field of tracing of drains to determine where the drains lead.

BACKGROUND OF THE INVENTION

The New Illustrated Science and Invention Encyclopedia, © 1987, 1989 by Marshall Cavendish Limited has articles on Plumbing (pp. 1989-1992), Pipelines (pp. 1949-1950), and Drainage (pp. 743-746) which give a good background, with illustrations, concerning how drainage systems are set up and how they work and also describe the components of a working drainage system.

Most buildings have a minimum of at least two different types of drainage systems; a storm drainage system and a sanitary, also known as the sewage, drain system. There are certain facilities (and/or buildings within that facility) that have a third drainage system. This third drainage system drains process waters into onsite holding tanks where the process water is treated before it is discharged off of the facility property or it is hauled away as waste that is to be dealt with outside the municipal sewage treatment system.

The storm drainage system is designed to convey rainwater and other forms of precipitation. Water collected from such precipitation is water in its purest form. This water should contain no contaminants. Because of this, storm drainage water can be discharged (untreated) into streams, rivers, lakes or the ground (water disposal via percolation).

The storm water system collects water from roof drains and some drains outside the building which collect water runoff from parking lots, sidewalks, lawns, etc. Storm drains convey water into a storm manhole and other drains which are typically routed to natural bodies of

water or to the ground. Storm drains are not typically routed to the sewer system and from there to the sewage treatment plant because, being natural precipitation, the material in a storm drain is not considered “contaminated” such that it needs treatment. Furthermore, the volume of storm water is such that if all the rainwater collected was routed to the sewage treatment system, the sewage treatment system would probably be overwhelmed and in order to prevent flooding, untreated sewage would have to be released. This release of untreated sewage is undesirable from an environmental point of view as well as from a legal point of view. It is undesirable from an environmental point of view as raw sewage is not good for any natural ecosystem. It is undesirable from a legal point of view as there are specific laws which prohibit such actions from taking place.

In contrast to storm drainage systems, sanitary drains are designed to drain material into a sewage treatment system and from there the material in the sewage treatment system is conveyed to the sewage treatment plant for treatment.

Problems occur when storm drains are mistakenly cross-connected to sanitary piping. The most serious difficulty occurs whenever heavy amounts of precipitation happen during a relatively short amount of time leading to an excess amount of water being forced through cross-connections into the sanitary piping, where the excess water ends up in the sewage treatment system. This leads to the undesirable situation where the sewage treatment plant has to discharge untreated sewage in order to avoid having their system become overwhelmed with excess water. This discharge of untreated sewage usually puts the sewage treatment plant out of compliance with local, state and Federal water quality laws and regulations.

Problems also occur when sanitary drains are mistakenly cross-connected to storm piping. There is nothing good about the prospect of having untreated sewage present in drains designed to convey only rain water or melted snow. When sewage is present in the storm water system it is considered a “release of untreated sewage” into the environment.

5 This release of untreated sewage is undesirable from an environmental point of view as well as from a legal point of view. It is undesirable from an environmental point of view as raw sewage reeks havoc on the ecosystem downstream. It is undesirable from a legal point of view as there are specific laws that prohibit discharge of untreated sewage and provide for legal sanctions against the building owners as being responsible for causing the release.

10 Cross-connections of storm drains into sanitary drainage systems and cross-connections of sanitary drains into storm drainage systems are a fact of life in modern society. Finding these cross-connections and fixing them is a responsibility of property owners. Another reality is that the current building owners are not always the same as the people who owned the building when it was built and the plumbing installed. Therefore the
15 current building owners are not always in the best position to understand how the plumbing in the building was installed in the first place.

It is understood that it is standard procedure in designing the plumbing in a new building or even working on the plumbing in an existing building to have blueprints showing each and every pipe and each and every drainage line and where it is supposed to
20 drain. However, it is often true that the paperwork showing where the drains are and where they drain to, does not always match the reality of where the drains are and where they drain. Therefore, methods of tracing drains to determine where material in a drain ends up are often needed to be used to determine where the existing drains are draining.

Current known methods of tracing drains to find out where the material in the drain drains to include a method known as the “Hot Water” method. Because storm water is normally cool (from about 55° F to about 90° F), hot water (water at a temperature greater than 100°F) can be added to each floor drain at a continuous rate. This hot water can then be “looked for” at a storm water manhole by using a remote thermometer to register the actual temperature of the water, noting any sudden increase in the temperature of the water. The advantage of this method is that it is very non-expensive.

The disadvantage of this “Hot Water” method is that it is not very conclusive. If there were only one “cross-connected” drain in a building (and this was known beforehand) this method might work adequately. However, the “Hot Water” method cannot conclusively prove that any one drain was bad because there could be other reasons why the temperature of the water might be elevated. For example, if a sink, which just happened to have hot water running, were to be plumbed to the storm water drain, and if that sink were running during the time another drain was being tested, this would skew the results.

Other known current methods to determine where drains drain to, require the use of visible dyes, other types of dyes, and/or radioactive materials that are detectable either by sight or by the use of an analytical instrument such as, but not limited to, a Geiger counter. In the following table, the use listed for each dye is one example of a suitable use for the visible dye, other types of dye, and/or radioactive materials.

Table

	<u>Substance</u>	<u>Use</u>
	(1) Brilliant Blue dye	field irrigation tracing
	(2) Bromide	field irrigation tracing
5	(3) Bromide	tile drains for fields
	(4) Chloride	groundwater, subsurface drains
	(5) Deuterium isotope	storm sewers*
	(6) Radionuclides	sewer discharge**
	(7) O ¹⁸ isotope	groundwater***
10	(8) Lithium chloride	streams/mine drainage
	(9) Fluorescent tracers	sewage discharge into seawater****, hydrological studies of aquifers, streams, rivers, etc.
	(10) Metal ions (e.g., lithium)	hydrological studies of aquifers, streams, rivers, etc.
	(11) Bacteria	hydrological studies of aquifers, streams, rivers, etc.
15	*as described in "Urban Stormwater Tracing with the Naturally Occurring Deuterium Isotope", by Sidle et al., Water Environ. Res. 71(6), pp. 1251-1256 © 1999.	
	** as described in "Sedimentation Basin Investigation Using Radiotracers" by Chmielewski et al, Institute of Nuclear Chemistry and Technology, Warsaw, Poland, 15, 79, pp. 481-487, © 2001.	
20	***as described in "Infiltration and Hydraulic Connections from the Niagara River to a Fractured-Dolomite Aquifer in Niagara Falls, New York", by Yager et al., J. Hydrol. (Amsterdam), 206(1-2), pp. 84-97, © 1998.	
	****as described in "Tracer Techniques to Evaluate the Dilution Performance of Sewage Submarine Outfall", by Roldao et al, Water Pollution IV: Modell., Meas. Predict., Int. Conf., 4 th , pp. 185-194 (1997).	
25	Materials indicated above are available from many sources, including Norlab Inc., P.O. Box 380, Amherst, Ohio 44001 USA (telephone no. 1-800-247-9422).	

The currently known visible dyes, other types of dyes and radioactive tracer materials require either visible review of the material in the drain, leading to labor-intensive and sometimes dangerous positioning of workers in difficult-to-reach locations (such as

being face down in the middle of a street looking into a manhole with a flashlight) in order to look for visible dye, or the use of analytical devices, or the use of radioactive materials and Geiger counters, which are not always desirable to use around people and animals.

Furthermore, it is usually never desirable to use a visible dye in circumstances where
5 the change in color of the water can be noticed and commented on by the general public.

The article, "Practical Applications of Tracers—Beyond Product Monitoring, by John E. Hoots, Presented at the 1990 Cooling Tower Institute Annual Meeting in Houston, Texas on February 5-7, 1990, describes the addition of very low concentrations of a chemical tracer to cooling water systems in order to be able to quantify previously
10 unaccounted blowdown, leakage, time of travel of cooling water to nearby waterways, and out-of-specification operating conditions.

U.S. Patent No. 5,304,800, issued April 19, 1994 to Hoots et al., describes and claims a process for detecting leakage from a process fluid to a temperature-conditioning fluid in an industrial process using a "tracer chemical".
15

It would be desirable to have a method of determining where drains lead that offers an alternative to the labor-intensive use of visible dyes or of radioactive materials.

SUMMARY OF THE INVENTION

The first aspect of the claimed invention is a method of tracing drains in a building comprising:

- (1) surveying the building to locate all existing drains;
- 5 (2) numbering all of the existing drains;
- (3) creating a Master Blueprint and a Master Spreadsheet showing all of the drains;
- (4) using a tracer to determine whether the storm water from the building actually flows from each storm drain to the storm water manhole and recording the information determined about the flow pattern of each storm drain tested on the Master Blueprint and on the Master Spreadsheet;
- 10 (5) selecting the test location to withdraw the sample of water, wherein said test location is selected from the group consisting of all storm manholes and all sanitary manholes;
- (6) running water continuously through a drain that drains into the test location manhole selected in Step (5);
- 15 (7) selecting a target sanitary drain and adding an amount of non-toxic fluorescent tracer to the target sanitary drain, wherein the amount of non-toxic fluorescent tracer added is such that the fluorescent signal of non-toxic fluorescent tracer is detectable over the background fluorescence of the water in said sanitary drain;
- 20 (8) using a fluorometer to detect the fluorescent signal of said non-toxic fluorescent tracer in the sample of water withdrawn at the test location selected in Step (5);
- (9) using the fluorescent signal to determine whether the target sanitary drain is draining to the test location selected in Step (5) and recording the information determined

about the flow pattern of said target sanitary drain on the Master Blueprint and on the Master Spreadsheet;

- (10) repeating Steps (4), (5), (6), (7), (8) and (9) as necessary such that all sanitary drains are traced; and
- 5 (11) using the information from the Master Blueprint and Master Spreadsheet to determine where all sanitary drains and storm drains are draining.

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210

The second aspect of the claimed invention is a method of tracing drains in a building comprising:

- (1) surveying the building to locate all existing drains;
- (2) numbering all of the existing drains;
- 5 (3) creating a Master Blueprint and a Master Spreadsheet showing all of the drains;
- (4) using a tracer to determine whether the storm water from the building actually flows from each storm drain to the storm water manhole and recording the information determined about the flow pattern of each storm drain tested on the Master Blueprint and on the Master Spreadsheet;
- 10 (5) selecting the test location to withdraw the sample of water, wherein said test location is selected from the group consisting of all storm manholes and all sanitary manholes;
- (6) running water continuously through a drain that drains into the test location manhole selected in Step (5);
- 15 (7) selecting a target sanitary drain and adding an amount of non-toxic fluorescent tracer to the target sanitary drain, wherein the amount of non-toxic fluorescent tracer added is such that the concentration of non-toxic fluorescent tracer is at least about 600 ppm in the water in said target sanitary drain;
- (8) using a fluorometer to detect the fluorescent signal of said non-toxic fluorescent tracer in the sample of water withdrawn at the test location selected in Step (5);
- 20 (9) using the fluorescent signal to determine whether the target sanitary drain is draining to the test location selected in Step (5) and recording the information determined

about the flow pattern of said target sanitary drain on the Master Blueprint and on the Master Spreadsheet;

- (10) repeating Steps (4), (5), (6), (7), (8) and (9) as necessary such that all sanitary drains are traced; and
- 5 (11) using the information from the Master Blueprint and Master Spreadsheet to determine where all sanitary drains and storm drains are draining.

10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
221

The third aspect of the claimed invention is a method of tracing drains of interest in a building comprising:

- (1) surveying the building to locate the drains of interest;
- 5 (2) numbering all of the drains of interest;
- (3) creating a Master Blueprint and a Master Spreadsheet showing all of the drains of interest;
- (4) using a tracer to determine whether the storm water from the building actually flows from the storm drains of interest to the storm water manhole and recording the information determined about the flow pattern of each storm drain tested on the Master Blueprint and on the Master Spreadsheet;
- 10 (5) selecting the test location to withdraw the sample of water, wherein said test location is selected from the group consisting of all storm manholes and all sanitary manholes;
- 15 (6) running water continuously through a drain that drains into the test location manhole selected in Step (5);
- (7) selecting a target sanitary drain of interest and adding an amount of non-toxic fluorescent tracer to the target sanitary drain of interest, wherein the amount of non-toxic fluorescent tracer added is such that the fluorescent signal of non-toxic fluorescent tracer is detectable over the background fluorescence of the water in said target sanitary drain of interest;
- 20 (8) using a fluorometer to detect the fluorescent signal of said non-toxic fluorescent tracer in the sample of water withdrawn at the test location selected in

Step (5);

(9) using the fluorescent signal to determine whether the target sanitary drain of interest is draining to the test location selected in Step (5) and recording the information determined about the flow pattern of said target sanitary drain of interest on the Master Blueprint and on the Master Spreadsheet;

(10) repeating Steps (4), (5), (6), (7), (8) and (9) as necessary such that all sanitary drains of interest are traced; and

(11) using the information from the Master Blueprint and Master Spreadsheet to determine where the sanitary drains of interest and the storm drains of interest, are draining.

The fourth aspect of the claimed invention is a method of tracing drains of interest in a building comprising:

- (1) surveying the building to locate the drains of interest;
- (2) numbering all of the drains of interest;
- 5 (3) creating a Master Blueprint and a Master Spreadsheet showing all of the drains of interest;
- (4) using a tracer to determine whether the storm water from the building actually flows from the storm drains of interest to the storm water manhole and recording the information determined about the flow pattern of each storm drain tested on the Master Blueprint and on the Master Spreadsheet;
- 10 (5) selecting the test location to withdraw the sample of water, wherein said test location is selected from the group consisting of all storm manholes and all sanitary manholes;
- (6) running water continuously through a drain that drains into the test location manhole selected in Step (5);
- 15 (7) selecting a target sanitary drain of interest and adding an amount of non-toxic fluorescent tracer to the target sanitary drain of interest, wherein the amount of non-toxic fluorescent tracer added is such that the concentration of non-toxic fluorescent tracer is at least about 600 ppm in the water in said target sanitary drain of interest;
- 20 (8) using a fluorometer to detect the fluorescent signal of said non-toxic fluorescent tracer from the sample of water withdrawn at the test location selected in Step (5);
- (9) using the fluorescent signal to determine whether the target sanitary drain of interest is draining to the test location selected in Step (5) and recording the information

determined about the flow pattern of said target sanitary drain of interest on the Master Blueprint and on the Master Spreadsheet;

(10) repeating Steps (4), (5), (6), (7), (8) and (9) as necessary such that all sanitary drains of interest are traced;

5 (11) using the information from the Master Blueprint and Master Spreadsheet to determine where the sanitary drains of interest and the storm drains of interest are draining.

11/11/2011 11:11:11 AM

DETAILED DESCRIPTION OF THE INVENTION

Throughout this patent application the following terms have the indicated

5 definitions:

“aka” means “also known as”.

ALDRICH refers to Aldrich, P.O. Box 355, Milwaukee, WI 53201 USA., telephone
number (800) 558-9160.

10 CAS Registry No. refers to the Chemical Abstracts Service Registry No. for a
compound.

LANCASTER refers to Lancaster Synthesis Inc., P.O. Box 1000, Windham, NH
03087-9977, telephone number (800) 238-2324.

Nalco refers to ONDEO Nalco Company, ONDEO Nalco Center, 1601 W. Diehl
Road, Naperville IL 60563, telephone number (630) 305-1000.

15 The first step in the instant claimed invention is to survey the selected building to
locate all the existing drains. The survey can include all of the drains in the building, or if
desired, the survey can include only those drains of interest. When reporting the results of
this method, it is important to note whether all of the drains in the building were surveyed
and tested, or whether the method surveyed and tested drains of interest only.

20 This survey typically begins with reviewing the blueprints for the building.
Preferably the blueprints reviewed should be those labeled “As Built” as compared to those
labeled “Proposed” because, as is known to ordinary people of skill in the art of blueprints,
the “As Built” blueprints better reflect the actual structure that was built. Whatever

blueprints are available, the blueprint with the best information should be chosen as the basis for the “Master Blueprint” and for the “Master Spreadsheet” that are to be created by following the method of the instant claimed invention.

If no blueprints are available for review, then the survey of the building to physically locate the drains and pipes will be the first step in the creation of a “Master Blueprint” and “Master Spreadsheet”. The Master Blueprint is created to show where all the drains are by representing the drains pictorially, whereas the Master Spreadsheet is created to show written information about each drain, when it was tested and what the results of the tests were.

After the blueprints have been reviewed or it has been determined that there are no blueprints to review, the survey process continues with an on-site inspection of the building. All drains need to be physically located--from the roof to the basement. The inspection typically, though not always, starts with the roof and proceeds downward through the building. All drains located should be checked against the best available blueprint and the actual location of the drains and any discrepancy between the blueprint and the actual building should be noted on the Master Blueprint and Master Spreadsheet that are being created during the method of the instant claimed invention.

In surveying the building for drains, examples of drains to be noted on the blueprint include sinks, floor drains, urinals, toilets, cup drains, roof drains, cooling tower overflows, cooling tower blowdowns, outside storm drains, and water fountains. If any drain is believed to be covered for any reason (carpet, raised floor, etc), the covered drain is marked down and noted as such, so that if the drain is ever uncovered, the Master Blueprint and Master

Spreadsheet will both show that at the point in time the method of the instant claimed invention was conducted this particular drain was unable to be tested due to limited access.

It is recommended, though not required, that the different types of drains and pipes be marked down with their own particular symbol to make it easier to distinguish between them. There are as many different symbols for drains and pipes as there are people working on blueprints. All symbols are acceptable as long as they are unambiguous. One set of acceptable useful symbols for certain drains and process piping is the following:

●	manhole or m.h
○	cleanout or c.o.
⊙	downspout (roof drain)
■	floor drain or f.d.
⊠	catch basin or c.b.
▣	sink
— — — — —	sanitary sewer
- - - - -	process sewer (underground)
— — — — —	process sewer (above ground)
— · — · — · — · — ·	storm sewer
—LW —LW —LW—LW—	lab waste

When the use of additional specific identification symbols for “specialized” drains becomes necessary or desirable, then individual symbols for specific drains can be created by the method operator. The only criteria for selection and use of these symbols is that a master “key” be kept readily available, so people not familiar with the method of the instant

claimed invention can still read and understand where each drain is and what material is supposed to be draining through the drain.

Step two in the method of the instant claimed invention is to unambiguously number all of the drains and use the unambiguous number for each drain to input the drain identification onto a Master Spreadsheet listing all of the drains in the building. There are as many different ways to unambiguously number the drains as there are people working with drains. One acceptable method of numbering the drains is as follows. The drains are first numbered on the blueprint starting with one and increasing until the last drain has been counted. The numbering starts in the lowest room number. The drains are counted in increasing order starting with the most northern drain in that room and then reading from west to east. The next higher room number will be next, and this procedure will be followed until all of the rooms are completed and all the drains are numbered.

After all the drains have all been numbered, Step (3) in the process of the instant claimed invention is to use the information gathered in Step (1) and Step (2) to create the Master Spreadsheet and the Master Blueprint. The Master Blueprint and the Master Spreadsheet will be used throughout the remainder of the method as the repositories for the information collected.

One acceptable layout for a Master Spreadsheet is as follows.

Table I
Master Spreadsheet

5

<u>Drain #</u>	<u>Nomenclature</u>	<u>Time dye added</u>	<u>Test#</u>	<u>Results of test</u>
1	Fuzzybldg-002-S-A	8:37a	2	
2	Fuzzybldg-002-FD-A	8:40a	2	
3	Fuzzybldg-002-S-B	8:44a	2	
4	Fuzzybldg-002-FD-B	8:45a	2	
5	Fuzzybldg-003-FD-A	8:51a	2	
6	Fuzzybldg-003-S-A	8:53a	2	
7	Fuzzybldg-005-S-A	8:55a	2	

It is to be noted, that each drain included in the Master Spreadsheet has been named using a particular nomenclature suitable for unambiguously identifying drains and their relative position within the target building, the building being identified as “Fuzzybuilding” or “Fuzzybldg” for purposes of this patent application. This nomenclature allows each drain to be unambiguously identified compared to all of the other tested drains. The following table gives one possible type of nomenclature for the drains, with the nomenclature being used being very descriptive. The nomenclature selected was chosen to give the building name, room number, drain type, and an individual drain letter for each drain:

Table II**Nomenclature for Drain Identification**

Using this as the pattern for drain identification

5

Building - Room # - Drain Type - Drain Letter

Abbreviation	Drain Type
FD	Floor Drain
RD	Roof Drain
CD	Cup Drain
TO	Cooling Tower Overflow
TB	Cooling Tower Blowdown
OD	Outside Storm Drain
WF	Water Fountain
T	Toilet
S	Sink
UR	Urinal

The drain letter is assigned in an order in the same manner as the drain number (furthest north, read west to east). The drain letters are specific to the particular type of drains. So if there were, for example, two sinks and one floor drain in room 104 of Smoothbldg, the nomenclature of the three drains would be

10

Smoothbldg-104-S-A;

Smoothbldg-104-S-B; and

Smoothbldg-104-FD-A.

Some drains will not easily fit into this or any other numbering system. For instance, if a drain is missed while surveying and found during testing, or if the drain had been added between surveying and testing, the drain will not be able to be numbered according to the method described above without changing the numbers of all of the drains after it. To eliminate renumbering the drains every time a new drain is found, the newly discovered drain can be numbered one higher than the drain with the previous highest number designation. If this procedure is followed, although a drain may not sequentially fit into the pattern of drain nomenclature identified previously, all of the drains will always be clearly marked on the Master Blueprint and Master Spreadsheet.

The fourth step in the process of the instant claimed invention is using a tracer to determine whether the storm water from the building actually flows from each storm drain to the storm water manhole and recording the information determined about the flow pattern of each storm drain tested on the Master Blueprint and on the Master Spreadsheet. It is typically the case that not all storm drains drain into the storm water drainage system. Instead of draining into the storm water drainage system, some storm drains drain into percolating ditches and eventually drain directly into the ground. Other storm drains simply drain directly into the ground. Therefore, the need for the fourth step in the process of the instant claimed invention is to determine whether the storm water from the building draining from roof drains and even outside storm drains actually flows from each storm drain to the storm water manhole as designed. This is done to help prevent any storm system serving the building from being untested.

Step (4) can be conducted using any of the known test methods for tracing drains. Known test methods include visual dyes such as, but not limited to, fluorescein (aka

yellow/green dye) and rhodamine WTS (aka red dye). These dyes are available from many standard chemical or chemical instrument supply companies, including the Cole-Parmer Instrument Company, (800) 323-4340.

The test for storm water is typically conducted by tracing the main storm drain that is supposed to lead to the storm water manhole or manholes that was or were designed to pick up all of the buildings' storm water. The test is conducted by placing the supplier's recommended amount of visible dye in the storm drain and looking for the color of the dye in the storm water manhole. This is done for each storm drain, usually using different colors of dye or waiting for enough time to pass to have the color of the dye "clear out" of the storm manhole.

An alternative to the use of visible dyes to trace the storm drains, is the use of a non-toxic fluorescent tracers. Suitable non-toxic fluorescent tracers are selected from the group consisting of

- Acridine Orange (CAS Registry No. 65-61-2),
- 2-anthracenesulfonic acid, sodium salt (CAS Registry No. 16106-40-4),
- Anthrasol Green IBA (CAS Registry No. 2538-84-3, aka Solubilized Vat Dye),
- bathophenanthroline disulfonic acid disodium salt (CAS Registry No. 52746-49-3),
- amino 2,5-benzene disulfonic acid (CAS Registry No. 41184-20-7),
- 2-(4-aminophenyl)-6-methylbenzothiazole (CAS Registry No. 92-36-4),
- Brilliant Acid Yellow 8G (CAS Registry No. 2391-30-2, aka Lissamine Yellow FF, Acid Yellow 7),
- Celestine Blue (CAS Registry No. 1562-90-9),
- cresyl violet acetate (CAS Registry No. 10510-54-0),

dibenzofuransulfonic acid, 1-isomer (CAS Registry No. 42137-76-8),
dibenzofuransulfonic acid, 2-isomer (CAS Registry No. 257627-62-2),
1-ethylquinaldinium iodide (CAS Registry No. 606-53-3),
fluorescein (CAS Registry No. 2321-07-5)
5 fluorescein, sodium salt (CAS Registry No. 518-47-8, aka Acid Yellow 73, Uranine),
Keyfluor White ST (CAS Registry No. 144470-48-4, aka Flu. Bright. 28),
Keyfluor White CN (CAS Registry No. 16470-24-9),
Leucophor BSB (CAS Registry No. 68444-86-0, aka Leucophor AP, Flu. Bright. 230),
Leucophor BMB (CAS Registry No. 16470-24-9, aka Leucophor U, Flu. Bright. 290),
10 Lucigenin (CAS Registry No. 2315-97-1, aka bis-N-methylacridinium nitrate),
mono-, di-, or tri-sulfonated naphthalenes, including but not limited to
1,5-naphthalenedisulfonic acid, disodium salt (hydrate) (CAS Registry No. 1655-29-4,
aka 1,5-NDSA hydrate),
2-amino-1-naphthalenesulfonic acid (CAS Registry No. 81-16-3),
15 5-amino-2-naphthalenesulfonic acid (CAS Registry No. 119-79-9),
4-amino-3-hydroxy-1-naphthalenesulfonic acid (CAS Registry No. 90-51-7),
6-amino-4-hydroxy-2-naphthalenesulfonic acid (CAS Registry No. 116-63-2),
7-amino-1,3-naphthalenedisulfonic acid, potassium salt (CAS Registry No. 79873-35-1),
4-amino-5-hydroxy-2,7-naphthalenedisulfonic acid (CAS Registry No. 90-20-0),
20 5-dimethylamino-1-naphthalenesulfonic acid (CAS Registry No. 4272-77-9),
1-amino-4-naphthalene sulfonic acid (CAS Registry No. 84-86-6),
1-amino-7-naphthalene sulfonic acid (CAS Registry No. 119-28-8), and
2,6-naphthalenedicarboxylic acid, dipotassium salt (CAS Registry No. 2666-06-0),

3,4,9,10-perylenetetracarboxylic acid (CAS Registry No. 81-32-3),

Phorwite CL (CAS Registry No. 12270-53-0, aka Flu. Bright. 191),

Phorwite BKL (CAS Registry No. 61968-72-7, aka Flu. Bright. 200),

Phorwite BHC 766 (CAS Registry No. 52237-03-3),

5 Pylaklor White S-15A (CAS Registry No. 6416-68-8),

1,3,6,8-pyrenetetrasulfonic acid, tetrasodium salt (CAS Registry No. 59572-10-0),

pyranine, (CAS Registry No. 6358-69-6, aka 8-hydroxy-1, 3, 6-pyrenetrisulfonic acid,
trisodium salt),

quinoline (CAS Registry No. 91-22-5),

10 Rhodalux (CAS Registry No. 550-82-3),

Rhodamine WT (CAS Registry No. 37299-86-8),

Safranine O (CAS Registry No. 477-73-6),

Sandoz CW (CAS Registry No. 56509-06-9, aka Flu. Bright, 235),

Sandoz CD (CAS Registry No. 16470-24-9, aka Flu. Bright. 220),

15 Sandoz TH-40 (CAS Registry No. 32694-95-4),

Sulforhodamine B (CAS Registry No. 3520-42-1, aka Acid Red 52),

Tinopal 5BM-GX (CAS Registry No. 169762-28-1),

Tinopol DCS (CAS Registry No. 205265-33-4),

Tinopal CBS-X (CAS Registry No. 27344-41-8),

20 Tinopal RBS 200,

Titan Yellow (CAS Registry No. 1829-00-1, aka Thiazole Yellow G), and

any existing ammonium, potassium and sodium salts thereof.

The preferred fluorescent tracers are 1,3,6,8-pyrenetetrasulfonic acid, tetrasodium salt and 1,5-naphthalenedisulfonic acid, disodium salt (hydrate).

These non-toxic, fluorescent tracers are available from chemical supply companies such as ALDRICH and LANCASTER. Certain of these non-toxic fluorescent tracers are available from Nalco under the names

TRASAR® 22199 for 1,5-naphthalenedisulfonic acid, disodium salt (hydrate) and **TRASAR® 23299** for 1,3,6,8-pyrenetetrasulfonic acid, tetrasodium salt.

The amount of non-toxic fluorescent tracer to use depends on the distance of the testing location from the building and the amount of fluorescent tracer required to be added to the storm drains to generate a detectable amount or “spike”. The “spike” must be separately detectable as compared to whatever background fluorescence is present in the water. Typically the operator of the fluorometer will “zero out” the fluorometer using a water sample taken before any non-toxic fluorescent dye is added to the water. Then the “spike” in fluorescent signal that is observed in the presence of non-toxic fluorescent dye is used to determine the presence of non-toxic fluorescent dye. A person of ordinary skill in the art of fluorometry knows how to set up and run a fluorometer such that the fluorometer is capable of detecting the fluorescent signal of any of the non-toxic fluorescent tracers listed previously.

As stated previously, it is necessary to use enough non-toxic fluorescent tracer so that the fluorescent signal of the non-toxic fluorescent tracer is detectable over the background fluorescence of the water being tested. The background fluorescence of the water being tested varies widely, from very little to a great deal. Therefore, it is recommended, though not required, to run a sample of the water to be tested through the

fluorometer before adding any non-toxic fluorescent tracer to the water. Once the background fluorescence is determined it is known to people of ordinary skill in the art of fluorescence, how much fluorescent tracer must be used such that the fluorescent signal of the non-toxic fluorescent tracer is detectable.

5 If time is of the essence or if it simply is desirable, it is possible to conduct the method of the instant claimed invention using an amount of fluorescent tracer such that the concentration of fluorescent tracer in the water being tested is at or above about 600 ppm. The 600 ppm figure has been found to be quite practical in testing water from many different buildings. Of course it is possible to put more non-toxic fluorescent tracer into the
10 water than 600 ppm. It may even be desirable, with water that has a very high relative background fluorescence, to use enough non-toxic fluorescent tracer so that about 1000 ppm of non-toxic fluorescent tracer is present in the drain water.

15 In using a non-toxic fluorescent tracer, the non-toxic fluorescent tracer is usually first diluted in a small amount of water to prevent the fluorescent tracer from getting caught and wasted in the lip of a drain. The drain is then flushed with about 5 gallons of pure water to push the fluorescent tracer through any traps that might be present.

If a non-toxic fluorescent tracer is used in conducting Step 4 of the method of the instant claimed invention, water from a storm manhole must be continuously pumped through a suitable fluorometer capable of detecting the fluorescent signal of the fluorescent
20 tracer. If there is not enough water in the storm manhole to pump, then it is necessary to run water continuously through the storm manhole so that there is enough water in the storm manhole to withdraw a sample for testing. The continuous running of water can be

accomplished by selecting a storm drain that is known to run to the storm manhole and running water through that storm drain.

If a non-toxic fluorescent tracer is used in conducting Step (4) of the method of the instant claimed invention a fluorometer is used to detect the emitted fluorescent signal of the non-toxic fluorescent tracer. Suitable fluorometers for this purpose are available from Nalco. The preferred fluorometer is a Trasar® 3000 fluorometer (hereinafter "the Unit"), available from Nalco. The Unit is preferably configured with valving so that the flow rate through the Unit is adjustable. Adjustable flow rate can become important as the flow through the Unit represents the amount of sample taken from the manhole. This sample size is important because the size of the sample (flow rate) and the amount of dye that is added to the upstream drain influence the size and curve of the "spike" which occurs on the graph, plotting the amount of fluorescence in parts per million per second of time. The Unit also records the actual time that the measurement was taken.

Any fluorometer used must be set up so that a sample of water from the test location, can be continuously run through the fluorometer. With the Unit, it is possible to configure the Unit, using a small, commercially available portable pump, such that a sample of water from the test location can be run through the Unit continuously. It is important to note when conducting the method of the instant claimed invention that it has been found that the initial surges of water through the Unit will have higher background fluorescence levels than the water that later flows through the piping.

In conducting Step (4) of the method of the instant claimed invention, if the tracer put into any storm drain is not detected in the storm water manhole, this indicates that there may be a direct drain of the storm water into the ground or the storm drain flows in an

unwanted “cross-connection” to the sanitary drain system or the storm drain flows into another, hitherto, unidentified storm manhole. One of the techniques to test the storm drains further can be tried if dye put into the storm drain being tested is not found in the storm drain manhole closest to the building then additional testing can be done by moving the point at which the dye is “looked for” in the storm drainage system downstream of the manhole that was first tested. It has been found, in conducting the method of the instant claimed invention, that often times storm drains will be connected downstream of the manhole that they were designed to flow to. The checking of storm drains draining into manholes downstream from where they should drain may continue until it no longer seems reasonable to do so.

If certain of the storm drains are not detected in any of the local storm manholes, additional testing can be conducted to see if those certain storm drains flow into any of the near-by sanitary manholes. This can be done by moving the test location from the storm manhole to the sanitary manhole and using a non-toxic fluorescent dye in the storm drain and using the fluorometer to determine whether the non-toxic fluorescent dye can be found in the sanitary manhole.

If certain of the storm drains are not detected to flow to the sanitary drain system, and all other options have been exhausted, it can be reasonably assumed that the storm drains discharge directly into the ground. This has been found to be the case in some of the older buildings that have been tested using the method of the instant claimed invention.

When the testing from Step (4) of the instant claimed method has been completed, all results should be recorded on the Master Blueprint and Master Spreadsheet. If anything is detected that contradicts the design (storm drain to sanitary, storm drain to different manhole

than designed) or the blueprints, it should be clearly noted and reported on the Master Blueprint, in the Master Spreadsheet and in any Summary Document prepared summarizing what was found when the method of the instant claimed invention was conducted.

After the storm water to storm manhole drainage pattern has been determined in Step (4), Step (5) in the process of the instant claimed invention is to select the proper test location to withdraw a sample of water from. The test location is selected from the group consisting of all storm manholes and all sanitary manholes. When looking for cross-connections between storm drains and sanitary piping, then the test location should be a sanitary manhole. When looking for cross-connections between sanitary drains and storm piping, then the test location should be a storm manhole.

Step (6) in the process of the instant claimed invention is to run water continuously through a storm drain that drains into the storm manhole, providing that it is that storm manhole that is the test location selected in Step (5). Alternatively, water should be run continuously through a sanitary drain that drains into the sanitary manhole, providing that the sanitary manhole is the test location selected in the Step (5). This running of water is required in order to make sure there is always sufficient water present in the test location so that a steady sample stream may be removed from the test location and run through the fluorometer. It is important to note that storm manholes are supposed to be absolutely dry except during periods of rain and sanitary manholes do not always have material in them either. It has been found when conducting the method of the instant claimed invention that nearly all of the manholes are dry when it is not raining. Of course the Method of the instant claimed invention cannot work if it is not possible to pump water out of the manhole to put through the Unit.

To ensure that there is a proper flow of water through manholes, water can be added continuously with water hoses to the storm drain that takes the longest amount of time to drain to the storm manhole that is the test location within the building drainage system. This ensures that any water (and non-toxic fluorescent tracer) that is introduced via a drain is
5 flushed to the manhole being tested. Of course if the test location is a sanitary manhole, then water can be run continuously through the sanitary drain that takes the longest amount of time to drain to the sanitary manhole that is the test location.

Step (7) in the process of the instant claimed invention is the selection of a target sanitary drain for testing. The target sanitary drain is tested by adding a non-toxic
10 fluorescent tracer to the drain and flushing the target drain continuously with water from the hose. When the non-toxic fluorescent tracer is detected by the Unit, the next target sanitary drain is tested in the same manner.

As was the case in Step (4), if a fluorescent tracer was used, in using a non-toxic
15 fluorescent tracer, the non-toxic fluorescent tracer is usually first diluted in a small amount of water to prevent the fluorescent tracer from getting caught and wasted in the lip of a drain. The drain is then flushed with about 5 gallons of pure water to push the fluorescent tracer through any traps that might be present.

The non-toxic fluorescent tracer chosen is selected from the group consisting of those materials previously identified in the description of Step (4) as being suitable
20 fluorescent tracers. The preferred non-toxic fluorescent tracers for use in Step (7) of the instant claimed invention are 1,3,6,8-pyrenetetrasulfonic acid, tetrasodium salt and 1,5-naphthalenedisulfonic acid, disodium salt (hydrate).

As was stated in the description of Step (4) the amount of non-toxic fluorescent tracer used in Step (7) depends on the distance of the testing location from the building and the amount of fluorescent tracer added to the storm drains to generate a detectable amount or “spike”. It is necessary to use enough non-toxic fluorescent tracer so that the fluorescent signal of the non-toxic fluorescent tracer is detectable over the background fluorescence of the water being tested. The background fluorescence of the water being tested varies widely, from very little to a great deal. The background fluorescence of grey water (water in a sanitary drainage system that contains no human waste products, yet does contain drain water from other sources) would be expected to be greater than that of storm water, though not as high as the background fluorescence of drains containing human waste products.

Therefore, it is recommended, though not required, to run a sample of the water to be tested through the fluorometer before adding any non-toxic fluorescent tracer to the water. Once the background fluorescence is determined it is known to people of ordinary skill in the art of fluorometry, how much fluorescent tracer must be used such that the fluorescent signal of the non-toxic fluorescent tracer is detectable.

As was stated in the description of Step (4) if time is of the essence or if it simply is desirable, it is possible to conduct the method of the instant claimed invention using an amount of fluorescent tracer such that the concentration of fluorescent tracer in the water being tested is at or above about 600 ppm. The 600 ppm figure has been found to be quite practical in testing water from many different buildings.

As was stated in the description of Step (4), preferably, the fluorescent tracer is first diluted in a small amount of water to prevent the fluorescent tracer from getting caught in

the lip of a drain. The drain is then flushed with about 5 gallons of pure water to push the fluorescent tracer through any traps that might be present.

As was stated in the description of Step (4), water from the drain is continuously pumped through a suitable fluorometer capable of detecting the fluorescent signal of the fluorescent tracer. Suitable fluorometers are available from Nalco. The preferred fluorometer is a Trasar® 3000 fluorometer (hereinafter "the Unit"), available from Nalco. The Unit is preferably configured with valving so that the flow rate through the Unit is adjustable. Adjustable flow rate can become important as the flow through the Unit represents the amount of sample taken from the manhole. This sample size is important because the size of the sample (flow rate) and the amount of dye that is added to the upstream drain influence the size and curve of the "spike" which occurs on the graph, plotting the amount of fluorescence in parts per million per second of time. The Unit also records the actual time that the measurement was taken.

Step (8) of the instant claimed invention involves using a fluorometer to detect the fluorescent signal of said non-toxic fluorescent tracer in the sample of water withdrawn at the test location selected in Step (5). The preferred fluorometer is the Unit. It is important to note that even though use of The Unit is preferred in Step (8), because it can automatically record and manipulate data, it is possible to conduct the method of the instant claimed invention by using a different fluorometer and manually recording the information detected by the fluorometer.

One of the reasons the use of the Unit is preferred is because when the Unit is in the preferred configuration where it records information every second, the Unit currently can store data for about 5 hours and 20 minutes before the data must be downloaded.

In conducting Step (7) and Step (8) of the method of the instant claimed invention every time non-toxic fluorescent tracer is added to a drain, the time should be recorded in a "test log sheet". One possible TEST LOG SHEET is as follows:

TEST LOG SHEET for Fuzzybuilding and Smoothbuilding <u>Cross Over Connection Study</u>			
Fuzzbldg and Smoothbldg Survey	UP	Water Continuously Added to Which Drains? (in order to ensure adequate passage of water through the storm water system so that the Unit is always registering a fresh sample)	134, 141
Building	Fuzzybldg	DataLogger Erased?	yes
Fuzzbldg Number	2010404	Time DataLogger Started	12:53p
Test Number	7	Time to Stop Adding fluorescent tracer	5:30p
Date	yesterday	Time DataLogger to be Shut Down	6:20p
Workers	Bob and Bill	Actual Time DataLogger Turned Off	5:17p
First Manhole Tested	bus stop	Hours & Minutes DataLogger Operated	4 hrs 24 min
Second Manhole Tested (needed if building has more than one storm drain system)		Time on watch	12:52p
Rooms with No Access		Time on Data Logger	12:52p

This next table is a sample page from a Master Spreadsheet used to mark down the time non-toxic fluorescent tracer is added to each drain. This time is then compared to when the “spike” of fluorescent signal is detected in the sample location and this information used to determine if the drain is draining to where it is supposed to be draining or it is cross-

5 connected in error:

<u>Drains Where Fluorescent tracer Was Added</u>		<u>Drains Where Fluorescent tracer Was Added</u>		<u>Drains Where Fluorescent tracer Was Added</u>		<u>Drains Where Fluorescent tracer Was Added</u>	
Drain ID	Time	Drain ID	Time	Drain ID	Time	Drain ID	Time
56	1:28p	91	2:14p	98	2:57p	109	4:01p
55	1:37p	92	2:18p	100	3:07p	110	3:59p
149	1:41p	85	2:24p	101	3:07p	123	4:20p
70	1:46p	86	2:24p	99	3:17p	124	4:18p
72	1:49p	84	2:27p	144	3:36p	122	4:28p
83	2:06p	93	2:33p	104	3:37p	118	4:29p

As stated previously, when configured to record data every second, the Unit can store data for about 5 hours and 20 minutes before the data must be downloaded to a computer. This gives the test operator about 5 hours to add non-toxic fluorescent tracer to drains. Non-toxic fluorescent tracer is added to as many drains as possible during the 5-hour period. Once the operating time of The Unit is up, the data can be downloaded onto a computer and can be analyzed to glean useful information from the test.

Of course, it is possible to configure the Unit to record data at different time intervals instead of every second.

It is also important to note that the flow rate through the manhole, the flow rate provided by the sump pump (that pushes the water through the Unit), the amount of non-toxic fluorescent dye that is added at the drain being tested, the amount of water that is used to flush the dye through the traps, the size of the piping being tested, the length of piping between the drain being tested and the manhole, all affect the "curve" that is generated using the Unit's DataLogger program. This curve can be used to determine which readings are true "spikes" and which readings are false background readings.

Step (9) of the instant claimed invention involves using the fluorescent signal to determine whether the target sanitary drain is draining to the test location selected in Step (5), or is cross-connected in error, and then recording the information determined about the flow pattern of said sanitary drain on the Master Blueprint and on the Master Spreadsheet. This information will then be reported on the Master Spreadsheet and Master Blueprint of the building.

Step (10) of the instant claimed invention is repeating Steps (4), (5), (6), (7), (8) and (9) as necessary such that all sanitary drains are traced.

Step (11) involves using the information from the Master Blueprint and Master Spreadsheet to determine where all sanitary drains and storm drains are draining.

5 In conducting this method, it is common to find drains that are not draining to where they are supposed to be draining. Additional testing is necessary to determine where these mis-connected or “cross-connected” drains are draining. This part of the method focuses on finding the drains that are cross-connected. After it has been determined that putting non-toxic fluorescent tracer into one of the tested sanitary drains generated a “spike” of
10 fluorescent signal in the storm system, the following factors can be used to hypothesize, analyze and attempt to determine which drain or drains could possibly have caused the “spike” in fluorescent signal detected:

- i) the time non-toxic fluorescent tracer was added to each sanitary drain;
- ii) the time the detectable “spike” of fluorescent signal was detected;
- 15 iii) the time it “normally” takes for roof drains to record a detectable “spike” of fluorescent signal (determined from Step (4) of the instant claimed method); and
- iv) Other factors based on the configuration of the actual drains.

If it is found that at least one of the sanitary drains were connected to the storm water drainage system, (for example, if the normal fluorescence reading is less than twenty, and a
20 spike of over 600 ppm is detected in the storm water drainage system) it will be necessary for the operator to go back and review the drains tested for each of the above-described factors. This review can be conducted in many possible ways. One such way is to assume that roof drains took a specific amount of time for their tracer signal to be detected (or to

“spike” as it is commonly described), it is reasonable to think that the sanitary drain would take approximately the same time for its fluorescent signal based on the non-toxic fluorescent dye added to be detected. This is where it is helpful to review the daily log to determine which drains fall into this time frame. However, other facts can also be considered when using this method during testing. For example, if water could be heard flowing at a specific drain (floor drain), it may be that the water heard might be the water that was being supplied to the roof drains to provide constant flow to the storm water manhole. This theory can be used to hypothesize that a specific drain was the drain that originally spiked. Once a hypothesis is in place, the next step is to retest the drain by itself to see if it spikes again as predicted. After concluding this review, the operator of the method will have selected the drain that is believed to be most likely to be the cross-connected drain.

Retesting a drain can be done using the exact procedure described above, except only one drain is tested at a time to make sure that the spike is indeed coming from the drain that is thought to be cross-connected. If the drain spikes in about the same time frame as the first test, it is concluded that the drain is indeed cross connected. If no spike occurs after an extended period of time, then the next most probable drain is tested. After a certain drain is identified as draining to the storm drains then the operator must determine whether other drains also drain to the storm drains.

If any drains are tested about the same time as the cross-connected drain, it is possible that the spikes could blend together. Therefore, all of the drains done at approximately the same time should ideally be retested to see if any more spikes in detectable fluorescent signal develop.

When the method is concluded it is recommended to summarize all of the findings in a report with drawings. The report should describe any drains that were found to be cross-connected, any mislabeled manholes, any discrepancies that were found between the drawings and what was actually constructed, as well as anything else of note to the owner of the building.

In this report, problem drains should be unambiguously identified. One such nomenclature system for identifying problem drains is as follows:

“ccd” for cross-connected drain

“bd” for bad drain or clogged drain

“ud” for unplumbed drain (uncommon, but has been found more than once)

After completing Step (11) of the method of the instant claimed invention it will be possible to instruct plumbers as to where and what type of repairs are required. After the repairs have been implemented the method of the instant claimed invention can be conducted again, to verify that the correct repairs have been made.

This method, when conducted correctly, is extremely reliable and repeatable. The process and equipment work very well.